# **SNP High Performances IR Microchip Series**

#### Key features

- Repetition rate up to 40kHz
- Ultrashort pulses down to 600ps
- Multi-kW peak power
- **Excellent beam quality TEM00, M<sup>2</sup><1.1**
- **Efficient**, air-cooled
- Sealed package, extremely long life



*teem* photonics™

For generating high peak power IR pulses of a few hundred picoseconds, microchip lasers are economical, compact, and reliable. 1064nm microjoule pulses are generated from a diode pumped passively Q-switched Nd:YAG microchip engine; the same package is used for either wavelength. The SNP series are designed for high average power, either from pulse energies of 20µJ at 1064nm, or from repetition rates up to 130kHz.

### **Applications**

- Material processing
  - o Cost effective marking solutions
  - o Graphitization
- Instrumentation
  - o Ranging
  - Differential absorption LIDAR
  - Super-continuum generation
  - o Distributed temperature sensing
  - Raman spectroscopy
- Biophotonics
  - o Nanosurgery
  - Protein cross-linking

# *teem* photonics™

### **Technical specifications:**

	SNP-08E-100	SNP-18E-100	SNP-20F-100	SNP-50F-100	SNP-130F- 100
Wavelength	1064nm	1064nm	1064nm	1064nm	1064nm
Repetition Rate	>5kHz	>13kHz	>19kHz	>45kHz	>130kHz
Constant Pulse width range (FWHM) <sup>(1)</sup>	<1ns	>3ns	<1ns	<0.7ns	<1.4ns
Output power <sup>(2)</sup>	>40mW	>300mW	>140mW	>190mW	>200mW
Output energy	>8µJ	>18µJ	>7µJ	>4µJ	>1.5µJ
Peak Power	>8kW	N/A	>10kW	>5.5kW	>1.1kW
Short term (1min) power stability <sup>(3)</sup>	<±1%	<±2%	<±1%	<±1%	<±1%
Long term (6 hrs) _ power stability <sup>(3)</sup> _	<±3%	<±5%	<±3%	<±3%	<±3%
Beam profile Full angle	Gaussian TEM00	Gaussian TEM00	Gaussian TEM00	Gaussian TEM00	Gaussian TEM00
divergence Horizontal@1/e <sup>2</sup> Vertical@1/e <sup>2</sup>	12 ± 2 mrad 14 ± 2 mrad	5.2±1 mrad <sup>(6)</sup> 5.1±1 mrad <sup>(6)</sup>	13±5mrad 13±5mrad	17±2.5mrad 17±2.5mrad	17±2.5mrad 17±2.5mrad
M <sup>2(4)</sup>	<1.3	<1.3	<1.3	<1.3	<1.3
Beam ellipticity <sup>(5)</sup>	<1.3	<1.3	<1.3	<1.3	<1.3
Polarization	Linear PER>20dB	Elliptical <sup>(7)</sup>	Linear PER>20dB	Linear PER>20dB	Linear PER>20dB
Package dimensions	115x29x36mm	145x42x36mm	145x42x36mm	145x42x36mm	145x42x36mm
Package weight	250g	300g	300g	300g	300g
Options (table p3)	None	None	F,M,S	F,M,S	F,M,S

Notes				
(1)	Measured with 1Ghz photodiode and 1GHz/10GS/s oscilloscope.			
(2)	Measurement performed with an OPHIR thermal power sensor (OPHIR 3A-FS-SH)			
(3)	For temperature variation $< \pm$ 3°C and $<$ 3°C/hour, stability is measured with calorimeter - detector band [DC, 2Hz]			
(4)	Mean average value M = $\sqrt{(XY)}$ , X and Y being respectively the major and minor axis of the ellipse			
(5)	Beam ellipticity is calculated as the ratio of the main axis far field divergence			
(6)	Collimated beam available as an option			
(7)	Linear polarization available as an option			

All information contained herein is believed to be accurate and is subject to change without notice. I eem Photonics may not be held lable for its use. Teem Photonics, its subsidiaries and affiliates, reserve the right to modify or withdraw, at any time and without any notice, specifications, product design, product component. Some options may not be available for all products. Please contact Teem Determine the interview of the SNP series - Page 2 of 5 www.teemphotonic<u>s.com</u> For your application, find your pulsed laser solution

# teem photonics™

## **Complementary information & options:**

Environment Parameters				
Operating Temperature Range	0-50°C			
Maximum Laser Head Baseplate Temperature	<50°C			
Maximum Power Consumption	<40W			
Laser Head Thermal Dissipation	<15W			
Storage Temperature	0-50°C			
Shock of 11ms according to IEC 68- 2-27, non operating	25g			
Vibration 5Hz to 500Hz sinusoïdal according to IEC 68-2-6	2g			


Certification				
Laser classification according to IEC 60825-1:2007	3В			
CDRH	Yes, if used with a -DR1 controller			
ROHs	Yes			

Options				
Multimode fibering (M)	Contact factory for availability			
Single mode fibering (F)	Contact factory for availability			
Synchronization output (S)	TTL compatible output signal for synchronization/monitoring			

Available Controller Types						
Model	Туре	Input Power	CDRH			
MLC-03A-DR1	Desktop	100-240 V AC	Yes			
MLC-03A-MR1	Module	12 V DC	No			
MLC-03A-BR1	Board	12 V DC	No			

All information contained nerein is believed to be accurate and is subject to change without notice, i eem Photonics may not be neid liable for its use. Teem Photonics, its subsidiaries and affiliates, reserve the right to modify or withdraw, at any time and without any notice, specifications, product design, product component. Some options may not be available for all products. Please contact Teem Photonics for details. November 13 SNP series - Page 3 of 5 www.teemphotonics.com

#### CDRH Laser Head Mechanical Drawings : SNP-18E-100, SNP-20F-100, SNP-50F-100 and SNP-130F-100



#### **CDRH Laser Head Mechanical Drawings : SNP-08E-100**

